

- Connect the feeder and the UR controller

My Daemon Swing	Accel Move:		CCW Angle Shake:
Flexibowl		 	
	Decel Move:		CW Angle Shake:
	Speed Move:		Count Shake:
	Angle Move:		Flip Count:
	Accel Shake:		Flip Delay:
	Decel Shake:		Test Move Test Shake Test Flip Test Blow
	Speed Shake:		Light Save Parameters
Power off	Speed	 	D D Simulation

CONNECT My Daemon Flexibowl run

192.168.143.120

Flexibowl IP:

directly

- Enable applications with UR Robot and FlexiBowl® without writing lines of code

- Control Multiple FlexiBowls at the same time

- Completely integrated

info@flexibowl.com